


№ п/п	Изображение	Артикул	Цена с НДС, руб.	Примечание
СЕРИЯ OCEANUS «SENSOR»				
1.		110031	12 240-00	АС (от розетки)
2.		110032	11 970-00	DC (от батареек)
3.		110033	7 650-00	АС (от розетки)
4.		110001	7 100-00	DC (от батареек)
5.		110190	8 160-00	АС (от розетки)
6.		110290	7 880-00	DC (от батареек)
7.		110070	9 000-00	АС (от розетки)
8.		110470	8 640-00	DC (от батареек)

9.		110270	9 690-00	АС (от розетки)
10		110370	9 240-00	DC (от батареек)
11.		110022	8 570-00	АС (от розетки)
12.		110023	8 000-00	DC (от батареек)
13.		110071	11 120-00	АС (от розетки)
14.		110072	10 890-00	DC (от батареек)
15.		110073	8 600-00	АС (от розетки)
16.		110074	8 210-00	DC (от батареек)

СЕРИЯ OCEANUS «TEMPOR»				
1.		100009	1 740-00	
2.		100001	2 850-00	
3.		100007	2 720-00	
4.		100006	2 690-00	
5.		100086	2 700-00	
6.		100029	3 190-00	
7.		100028	1 590-00	
8.		100030	1 700-00	

9.		100011	1 360-00	
10		100186	3 230-00	
11.		100014	1 910-00	
12.		100013	2 180-00	
13		100016	3 950-00	
СЕРИЯ OCEANUS «ПЕДАЛЬНЫЙ СМЫВ»				
1.		100012	1 970-00	
2		100023	2 320-00	

СЕРИЯ OCEANUS «СЛИВНЫЕ ТРАПЫ»				
1.		31090	600-00	
2.		31120	410-00	
3.		34000	1 300-00	
4.		34014	580-00	
5.		34025	750-00	
6.		34019	940-00	
7.		34018	940-00	
8.		31210	3 300-00	
9.		31220	800-00	